





**PRODUCT CONFROMS TO THE** 

**EUROPEAN STANDARD** 

# **ATLAS GEOFLEX EXPRESS**

rapid-setting highly flexible gel adhesive 2-15 mm

- for quick work foot traffic after only 2 hours
- grouting just after 2 hours
- installation of ceramic and stone tiles, porcelain stoneware, mosaics
- for use in communication routes, bathrooms, balconies and terraces
- perfect spread and no slip even with large tiles
- for critical substrates e.g. old tiles, terrazzo, plasterboards, damp- -proofing, floor heating, concrete and OSB
- wide range of mix water consistency adjusted to the needs
- for filling, thin- and thick-coat bonding
- application in temperatures from +5°C up to +35°C



# UNIQUE GEL TECHNOLOGY

# ATLAS GEOFLEX EXPRESS adhesive formulation uses the innovative technology of silicate gel in combination with fast-setting cement. This makes it possible to obtain:

- very rapid pre-setting, eliminating the possibility of building salts building up under the tiles and in their structure,

- rapid increases in adhesion and strength.

Silicate gel has a unique ability to bind water. Accumulation of a part of the mixing water ensures complete cement hydration, regardless of the type of the tiles. Thanks to appropriate water management, which is necessary to complete the setting process, the gel adhesive ensures full adhesion to substrates of various absorbency levels.

# The use of silicate gel technology in combination with fast-setting cement offers the following benefits:

- can be grouted after just 2 hours for rapid repair work,
- the possibility of bonding any type of cladding, both absorbent and non-absorbent,
- it is possible to optimally adapt the consistency of the adhesive to the individual preferences of the contractor and the needs of the application specific application, by dosing water over a much wider range than with traditional adhesives,
- achieving a full spread of adhesive under the panels, which improves the adhesion and durability of the fixing, especially in external applications,
- safe bonding of coverings on substrates exposed to direct sunlight (as long as the temperature does not exceed the permissible value), both during the tiling work and during the setting of the adhesive mortar.

# Properties

ATLAS GEOFLEX EXPRESS is manufactured as a dry mix of top quality cement binder, aggregates and special natural and synthetic modifiers.

**Rapid setting** – use of rapid setting cement in the adhesive formula allows for rapid increase of adhesion and strength, especially during the initial setting (first 2-3 hours after tiles installation). This ability enables to foot traffic and grouting just after 2 hours after tiles installation. The adhesive is recommended also for quick repairs of the floor (e.g. on balcony, terrace etc.)

#### The wide range of adhesive layer thicknesses (2-15 mm) allows:

- thin-coat cladding installation on even substrates,

- thin-coat cladding installation on uneven substrates, preceded by substrate floating,

 thick-coat cladding installation on uneven substrates, with no need for substrate floating

**No cladding slip** - enables installation of the cladding from top to bottom with no need of support at the fixing stage.

No shrinkage of the adhesive underneath the tile – no subsidence of the tiles during setting – works can be continued after a break with no risk of level difference.

**Resistant to changing atmospheric conditions** – allows for quick and safe works in various atmospheric conditions. Rapid strength gain by the adhesive limits possibility of damaging cladding during installation outside of the building.

# Purpose

CLADDING TYPE	
glazed tiles	+
terracotta	+
porcelain tiles	+
laminated tiles	use ATLAS ULTRA GEOFLEX
natural stone cladding (granite, marble, travertine, syenite, slate, etc.).	perform an application test*
clinker	+
stoneware	+
ceramic mosaic	+
glass mosaic	perform an application test*
glass, coloured, printed tiles, etc.	perform an application test* and check the recommendations of the tile manufacturer
concrete / cement mortar tiles	+
composite panels	use ATLAS ULTRA GEOFLEX
insulation and soundproofing panels	use ATLAS ULTRA GEOFLEX

\*for a description of the application test, see paragraph Important additional information

FORMATS OF INSTALLED ELEMENTS	
small, medium and large format tiles: ≤ 0.50 m <sup>2</sup> and with the length of the larger side ≤ 100 cm	+
large tile format (> 0.50 m <sup>2</sup> )	Use ATLAS ULTRA GEOFLEX
slim type tiles	Use ATLAS ULTRA GEOFLEX

TYPES OF OBJECT	
residential buildings	residential buildings
public, educational, office and healthcare buildings	+
commercial and service construction	+
religious buildings	+
industrial buildings and multi- storey garages	use ATLAS ULTRA GEOFLEX
industrial warehouses	use ATLAS ULTRA GEOFLEX
traffic construction	use ATLAS ULTRA GEOFLEX
SPA facilities	use ATLAS ULTRA GEOFLEX

PLACE OF INSTALLATION	
low-traffic areas	+
medium traffic areas	+
high traffic areas	+
kitchen, bathroom, laundry room, garage (in individual housing)	+
terraces	+
balconies, loggias	+
external slab stairs	+
external post stairs, e.g. cantilever stairs	use ATLAS ULTRA GEOFLEX
traffic routes	+
facades (including on thermal insulation systems)	use ATLAS ULTRA GEOFLEX
cladding of building plinths	+
process tanks, swimming pools, fountains, jacuzzis, balneotechnology (without aggressive chemicals)	use ATLAS ULTRA GEOFLEX
drinking water tanks	use ATLAS PLUS
saunas	use ATLAS ULTRA GEOFLEX
showers, washing facilities, rooms washed with large quantities of water	+

substrate type - standard	
cement floors and screeds	+
anhydrite screeds	+
cement and cement-lime plasters	+
gypsum plasters	+
cellular concrete	+
brick or silicate block walls	+
brick or hollow brick walls	+
gypsum block masonry	+

substrate type - difficult	
concrete	+
terrazzo	+
mineral, dispersion and reactive sealing coatings	+
plasterboard drywall	+
screeds (cement or anhydrite) with water or electrical underfloor heating,	+
screeds with heating mat embedded in the adhesive	+
plaster with wall heating	+
gypsum boards	+
gypsum fibre boards	+
cement fibre boards	+
existing ceramic or stone cladding (tile on tile)	only inside
resin varnishes for concrete bound to the substrate	+
dispersive, oil painting coats, bonded with substrate	+
timber floors (thickness >25mm)	use ATLAS ULTRA GEOFLEX
wood-based flooring panels , minimum 22 mm thick, fixed with ATLAS M-System fasteners	+
OSB/3, OSB/4 and particle board on the floor (thickness > 25mm)	+
OSB/3, OSB/4 and particle board on the wall (thickness > 18mm)	+
metal and steel surfaces	use ATLAS ULTRA GEOFLEX
plastic surfaces	use ATLAS ULTRA GEOFLEX

ATLAS GEOFLEX EXPERSS adhesive is also used for filling the abovementioned standard and difficult substrates.

# **Technical data**

	1
Bulk density	approx. 1.4 g/cm <sup>3</sup>
Mixing ratio	0.24 ÷ 0.30   / 1 kg
(water/dry mix)	6.0 ÷ 7.5 l / 25 kg
Min/max. adhesive thickness	2 mm ÷ 15 mm
Temperature of the adhesive preparation and of the substrate and surroundings during the work	from +5 °C to +35 °C
Maturation time	5 minutes
	approx. 45 minutes
Service life (stand-by time)*	(mixing ratio 0.24 l/kg
Service life (stand-by time)	approx. 75 minutes
	(mixing ratio 0.3 l/kg
Open time*	min. 20 minutes
Adjustability*	10 minutes
Walking on the floor/jointing*	after 2 hours
Pedestrian traffic load**	after 2-6 hours
Full operational loads - wheeled traffic**	after approx. 24 hours
Starting underfloor heating**	after 7 days
*) The times chown in the table are read	

\*) The times shown in the table are recommended for application conditions of approx. 23  $^\circ C$  and 55 % humidity.

\*\*) The times shown in the table are recommended for application conditions at approx. 23 °C and 55 % humidity, with an adhesive layer thickness of up to 5 mm. At lower temperatures and higher adhesive thicknesses, they may become longer. Storage of the product in open packaging may increase the setting time.

# **Technical requirements**

The product complies with the requirements of EN 12004+A1:2012 - C2FT - adhesive for tiles, cementitious tile adhesive with increased parameters, fast-setting, with reduced run-off, for indoor and outdoor use on walls and floors.

ATLAS GEOFLEX EXPRESS (2020) Declaration of performance 229/CPR. EN 12004:2007+A1:2012	
Intended use:	
Any interior and exterior installation of	of tiles.
Reaction to fire	A1/A1 <sub>fl</sub>
Bond strength defined as:	
Initial bonding	≥ 1.0 N/mm²
Early bonding	≥ 0.5 N/mm²
Bond durability in conditioning/thermal ageing conditions defined as: bonding after thermal ageing	≥ 1.0 N/mm²
Bond durability in water/damp conditions defined as: bonding after immersion in water	≥ 1.0 N/mm²
Bond durability in freeze-thaw cycles conditions defined as: bonding after freeze- thaw cycles	≥ 1.0 N/mm²

# Substrate preparation

#### The substrate should be:

**stable** - sufficiently load-bearing, resistant to deformation, free of substances that reduce adhesion and seasoned.

**even** - the maximum thickness of the adhesive is 15 mm, for levelling substrates with larger irregularities, e.g. ATLAS ZW 330 levelling mortar, ATLAS SMS, SAM or POSTAR underlays can be used.

**cleaned** - from layers that may impair adhesion of the adhesive, in particular from dust, dirt, lime, oil, grease, wax, oil and emulsion paint residues. Substrate covered with algae, mould fungi etc., should be cleaned and protected with ATLAS MYKOS NR 1 or ATLAS MYKOS PLUS,

#### primed

- ATLAS UNI-GRUNT or ATLAS UNI-GRUNT ULTRA - when the substrate has excessive or non-uniform absorptivity,

- ATLAS GRUNTO-PLAST - when the substrate has low absorption or is covered with layers limiting adhesion,

- ATLAS ULTRAGRUNT - when tiles will be fixed on critical substrates. damp proofed - when laying tiles on surfaces that are exposed to water

Detailed indications for the preparation of the substrate, depending on the type of substrate, are shown in the table at the end of the Technical Data Sheet.

# **Cladding installation**

#### Preparation of the adhesive

Pour the contents of the bag into a vessel with a measured amount of water (proportions given in the Technical Data) and mix with a slow-speed mixer with a mortar mixer until a uniform consistency is obtained. Set the mixed adhesive aside for 5 minutes and mix again. The adhesive thus prepared should be used within the time period described in the Technical Data table.

#### Application of adhesive

It is recommended to first rub a thin layer of adhesive into the substrate and then apply a thicker layer of adhesive, immediately profiling it with a notched trowel. It is recommended that the toothed trowel is guided in one direction as much as possible. On walls, it is recommended to profile the adhesive in a vertical direction.

In the case of tiles laid on floors and cladding carried out out outdoors, it is recommended that the bonding surface is complete (if necessary, use a combined method of applying adhesive mortar to the substrate and to the undersurface of the tile).

#### Bonding the cladding

After spreading on the substrate, the adhesive retains its properties for approximately 30 minutes (at a temperature of approximately 23 °C and 55 % humidity). During this time, apply the tile to it and press down carefully (the contact area between the tile and the adhesive should be even and as large as possible - min. 2/3 of the tile surface). Excess adhesive appearing in the joints when pressing the tiles should be removed continuously.

The width of the joints must be maintained depending on the size of the tiles and the operating conditions.

#### Correcting the position of the plate

The position of the tile can be corrected by gently moving it in the plane of bonding. This can be done up to approximately 10 minutes after pressing (at a temperature of approx. 23 °C and 55 % humidity).

#### Grouting and use of the cladding

The use of ATLAS mortars, e.g. ATLAS CERAMIC GROUT, is recommended for grouting the cladding. It is possible to step on the cladding and start grouting after about 2 hours after the tiles have been glued. Expansion joints between tiles, joints along wall corners, joints at sanitary facilities should be filled with ATLAS ELASTIC SANITARY SILICONE or ATLAS SANITARY SILICONE SILTON S.

## Consumption

The average adhesive consumption figures given in the table refer to application on an even substrate. Unevenness of the substrate increases the unit consumption of the adhesive mortar.

Tile size [cm]	Place of application	Recommende d trowel tooth size [mm]	Consumptio n rate [kg/m² ]
2 x 2	wall	4	1,3
2 X Z	flooring	4	1,3
10 × 10	wall	4	1,3
10 x 10	flooring	6	2,0
1E v CO	wall	6	2,0
15 x 60	flooring	8	2,5
20 x 25	wall	6	2,0
20 X 25	flooring	8	2,5
25 40	wall	6	2,0
25 x 40	flooring	8	2,5
2020	wall	6	2,0
30 x 30	flooring	8	2,5
20 60	wall	8	2,5
30 x 60	flooring	10	3,0
10 10	wall	8	2,5
40 x 40	flooring	10	3,0
5050	wall	8	2,5
50 x 50	flooring	10	3,0
60 60	wall	10	3,0
60 x 60	flooring	12	3,5
70 70	wall	10	3,0
70 x 70	flooring	12	3,5
tiles of the type	wall	8	2,5
board*, e.g. 20 x 90 or 15 x 100	flooring	10	3,0

\*for plank-type tiles, a combined laying method is recommended

If the mix combined method is used, the adhesive consumption will increase. When bonding floor coverings, using a 12 mm trowel with semi-circular teeth (flowing consistency 7.5 l water/25 kg mortar) - consumption 4.6 kg/m<sup>2</sup>.

## Packaging

Plastic bags: 25 kg, 22.5 kg Alubags: 5 kg

# Safety information

Safety information is provided on the product packaging and in the Safety Data Sheet available at <u>www.atlas.com.pl</u>.

### Storage and transport

Information on storage and transport is provided on the product packaging and in the Material Safety Data Sheet available at www.atlas.com.pl.

Shelf life of the product is:

- for product in plastic bags 12 months from the production date shown on the packaging,
- for product in alubags 24 months from the production date shown on the packaging.

#### Important additional information

Spreading under tile is achieved using a quantity of baking water from the upper end of the mixing ratio range, i.e. approximately 0.30 l per 1 kg of dry mix. Zero run-off is achieved using a quantity of baking water from the lower end of the mixing ratio interval, i.e. approximately 0.24 l per 1 kg of dry mix.

When cladding a balcony or terrace, the subfloor should be divided by expansion joints into areas of max. 3 x 3 m. It is possible to increase the size of the underlay dilatation fields up to 25 m<sup>2</sup> provided that forced dilatation is carried out in the cladding itself (recommended minimum of 4 cladding fields, each with a surface area of up to 9 m<sup>2</sup>).

When making the expansion fields, observe the requirement that the ratio of the shorter side to the longer side should be between 1:1 and 1:2. The expansion joints of the substrate should be transferred to the cladding and filled with ATLAS ELASTIC SANITARY SILICONE or ATLAS SANITARY SILICONE SILTON S. Forced expansion joints should be ATLAS ELASTIC SANITARY SILICONE or ATLAS SANITARY SILICONE SILTON S. The minimum thickness of the adhesive after pressing the tiles should be 4 mm. The adhesive must fill the entire space between the tile and the substrate.

All indicated technological break times, technical parameters of the product, etc. refer to standard setting conditions, i.e. at the temperature: +23°C (+/-2°), relative humidity: 55% (+/- 5%) and substrates defined in EN 1323 and tiles according to EN 176. In other heat and humidity conditions the indicated times may change.

Do not soak the tiles before gluing. When determining the thickness of the adhesive under the cladding to be glued, geometric deviations in the shape of the tiles, e.g. curling of the plane, must be taken into account. Before fixing natural stone tiles or glass elements, it is necessary to carry out an application test. For this purpose, one tile should be glued to the substrate. The bonding area should be 60 % (40 % of the tile surface should not be in contact with the adhesive). After 2-3 days, the appearance of the tile should be assessed. The test result can be considered positive if there are no shade differences on the tile surface between areas in contact and not in contact with the adhesive.

The open time - from applying the adhesive to the substrate to applying the tiles to it - is limited. To check whether it is still possible to stick the tiles, a simple test is recommended. This consists of pressing the fingers of your hand against the applied adhesive. If the glue remains on the fingers, then the tiles can be glued. When the adhesive does not stick to the fingers, remove it from the substrate and apply a new layer.

Clean the tools with clean water, immediately after using the adhesive. Difficult to remove remains of the bonded adhesive should be washed off with ATLAS CEMENT AWAY.

The information included in the Product Data Sheet constitutes basic guidelines concerning the use of the product and does not release from the obligation to conduct work according to the best construction practices and health and safety at work regulations. On the date of issue of this Product Data Sheet, all previous Product Data Sheets become invalid. The accompanying documents for the product are available at www.atlas.com.pl.

The content of the Product Data Sheet as well as the symbols and trade names used in it are the property of Atlas sp. z o. o. Their unauthorized use will be sanctioned.

Updated: 2022-05-04

The table below shows the specific requirements for substrate preparation. Before starting work, also refer to the Technical Sheets of the products listed in the table. The times shown in the table are recommended for application and seasoning conditions of approx. 20 °C and 50 % humidity.

Newly manufactured cementitious	Moisture content of the substrate 4.0 % CM
subfloors ATLAS POSTAR 10	- after approx. 1.5 days for a substrate thickness of 1.0-3.0 cm
	- after approx. 3 days for a substrate thickness of 3.1-5.0 cm
	- after approx. 9 days for a substrate thickness of 5.1-10.0 cm
Newly manufactured cementitious	Moisture content of the substrate 4.0 % CM
subfloors ATLAS POSTAR 20	- after approx. 1 day for an undercoat thickness of 1.0-3.0 cm
Submoors ATLAS POSTAR 20	
	- after approx. 2 days for a substrate thickness of 3.1-5.0 cm
	- after approx. 5 days for a substrate thickness of 5.1-8.0 cm
Newly manufactured cementitious	Moisture content of the primer 4.0 % CM
subfloors ATLAS POSTAR 60	- after approx. 6 hours for a substrate thickness of 1.0-3.0 cm
	- after approx. 12 hours for a substrate thickness of 3.1-5.0 cm
	- after approx. 40 hours for a substrate thickness of 5.1-8.0 cm
Newly manufactured cementitious	Moisture content of the primer 4.0 % CM
subfloors ATLAS POSTAR 80	- after approx. 3 hours for a substrate thickness of 1.0-3.0 cm
	- after approx. 6 hours for a substrate thickness of 3.1-5.0 cm
	- after approx. 18 hours for a substrate thickness of 5.1-8.0 cm
Newly manufactured cementitious	Moisture content of the substrate 4.0 % CM
subfloors ATLAS SMS 15	- after approx. 8 hours for an undercoat thickness of 1-15 mm
Newly manufactured cementitious	Moisture content of the primer 4.0 % CM
subfloors ATLAS SMS 30	- after approx. 18 hours for an undercoat thickness of 3-5 mm
	- after approx. 48 hours for an undercoat thickness of 6-10 mm
	- after approx. 72 hours for a substrate thickness of 11-20 mm
	- after approx. 96 hours for an undercoat thickness of 21-30 mm
Neurolus and an	
Newly manufactured cementitious	Moisture content of the primer 4.0 % CM
subfloors ATLAS SMS 80	- after approx. 4 days for a thickness of 25-40 mm
	- after approx. 6 days for a thickness of 41-60 mm
	- after approx. 9 days for a thickness of 61-80 mm
Other cement mortar underlays	Compressive strength of at least 12 MPa.
	Seasoning minimum 28 days
	Optimum moisture content < 4% by weight
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
Newly manufactured anhydrite	Moisture content of the underlay 1.0 % CM
underlays ATLAS SAM 100	- approx. 4 days for a thickness of 0.5-3.0 cm
	Moisture content of the underlay 0.5 % CM (when heating)
	- approx. 7 days for a thickness of 0.5-3.0 cm
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
Newly manufactured anhydrite	
, , ,	Moisture content of the underlay 1.0 % CM
underlay ATLAS SAM 200	- approx. 10 days for a thickness of 2.5-4.0 cm
	- approx. 21 days for a thickness of 4.1 to 6.0 cm
	Moisture content of the underlay 0.5 % CM (when heating)
	- approx. 18 days for a thickness of 2.5-4.0 cm
	- approx. 28 days for a thickness of 4.1-6.0 cm
	If a white surface deposit has appeared while the primer is drying, it should be removed mechanically by
	sanding and then the entire surface dusted.
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
Newly manufactured anhydrite	Moisture content of the underlay 1.0 % CM
underlayments ATLAS SAM 500	- approx. 4 days for a thickness of 2.0-4.0 cm
	- approx. 7 days for a thickness of 4.1 to 6.0 cm
	Moisture content of the underlay 0.5 % (when heating) CM
	- approx. 7 days for a thickness of 2.0-4.0 cm
	- approx. 18 days for a thickness of 4.1-6.0 cm
	Prime with one of the emulsions:
	Prime with one of the emulsions: - ATLAS UNI-GRUNT
	Prime with one of the emulsions: - ATLAS UNI-GRUNT - ATLAS UNI-GRUNT ULTRA
Cement and anhydrite underlays	Prime with one of the emulsions: - ATLAS UNI-GRUNT
Cement and anhydrite underlays with underfloor heating (heating	Prime with one of the emulsions: - ATLAS UNI-GRUNT - ATLAS UNI-GRUNT ULTRA
	Prime with one of the emulsions:         - ATLAS UNI-GRUNT         - ATLAS UNI-GRUNT ULTRA         Preparation in accordance with the same instructions as for normal primers. In addition, the subfloor must

Bricks or hollow bricks of calcium-	A two-layer render (render + filler) trowelled to a rough finish is required. Bonding directly to unrendered
silicate, ceramic or cellular concrete	masonry is only possible if the geometric requirements of the substrate are met. In this case, it is necessary
	to complete the wall with a full joint (or to complete the jointing) and to repair any defects and
	unevenness using ready-made mortars.
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
Concept and concept lines also	- ATLAS UNI-GRUNT ULTRA
Cement and cement-lime plasters	Seasoning minimum 3 days for every 1 cm of thickness
from ATLAS ready-mixed mortars	Optimum moisture content < 4% CM
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
<u></u>	- ATLAS UNI-GRUNT ULTRA
Other cement and cement-lime	Minimum CS category III
plasters	Minimum curing time of 7 days for each 1 cm of thickness Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
Current als store	- ATLAS UNI-GRUNT ULTRA
Gypsum plasters	Recommended compressive strength > 4 MPa. Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
	If the gypsum plaster is made in a wet room, then it should be carefully protected against moisture, e.g.
	by applying an insulating coating of ATLAS WODER E or WODER W
	Gypsum plaster should be removed
Mortar levelled substrates	Moisture content of the underlay 1.0 % CM
ATLAS ZW 330	- 5 hours at 5 mm film thickness
	- 10 hours at a film thickness of 10 mm
	- 20 hours for a layer thickness of 20 mm
	- 48 hours for layer thicknesses over 20 mm
Concrete floors	Minimum class C16/20
	Seasoning time minimum 3 months
	Optimum moisture content < 4% by weight
	Absolutely clean off any residue from concreting separators and other substances that may impair
	adhesion
	Repair deficiencies, chipping and other cavities with one of the mortars:
	- ATLAS TEN-10
	- ATLAS ZW 330
	- ATLAS FILER S
	Prime with ATLAS ULTRAGRUNT
Newly installed waterproofing with	- ATLAS WODER E, ATLAS SZYKOSCHNĄCA FOLIA W PŁYNIE tiling can start after 2 hours (for damp-
ATLAS WODER DUO, ATLAS WODER	proofing) and after 4 hours (for waterproofing)
DUO EXPRES, ATLAS WODER E,	- ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours
ATLAS SZYKOSCHNĄCA FOLIA W	- ATLAS WODER DUO - possibility to install the cladding after 12 hours
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and	
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S.	- ATLAS WODER DUO - possibility to install the cladding after 12 hours - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S.	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads.
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or</li></ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring Existing ceramic or stone tile	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul> Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT. Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate. <ul> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the ile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose. <ul> <li>the adhesion of the existing cladding to the substrate should be assessed by tapping the</li> <li>Remove any old tiles that have become detached from the substrate.</li> </ul></li></ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring Existing ceramic or stone tile	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.</li> <li>the adhesion of the existing cladding to the substrate should be assessed by tapping the a Remove any old tiles that have become detached from the substrate.</li> <li>fill cavities, e.g. with ATLAS ZW 330 mortar</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring Existing ceramic or stone tile	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.</li> <li>the adhesion of the existing cladding to the substrate should be assessed by tapping the</li> <li>Remove any old tiles that have beccome detached from the substrate.</li> <li>fill cavities, e.g. with ATLAS ZW 330 mortar</li> <li>Thoroughly clean and degrease the surfaces of the remaining tiles.</li> </ul>
ATLAS SZYKOSCHNĄCA FOLIA W LIQUIDNIE, ATLAS WODER W and ATLAS WODER S. Lastryko Oil paint and resin varnish coatings OSB and plank flooring Existing ceramic or stone tile	<ul> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty used to level the substrate.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> <li>OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.</li> <li>the system must not buckle under operating loads.</li> <li>for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.</li> <li>prime with ATLAS ULTRAGRUNT</li> <li>In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.</li> <li>the adhesion of the existing cladding to the substrate should be assessed by tapping the a Remove any old tiles that have become detached from the substrate.</li> <li>fill cavities, e.g. with ATLAS ZW 330 mortar</li> </ul>