



# **ATLAS GEOFLEX**

# highly flexible gel adhesive 2-15 mm



- for ceramic and stone cladding
- zero or full flow under tile
- entry onto the cladding and grouting after just 12 hours
- for filling, thin- and thick-coat bonding
- on difficult substrates, including concrete, terrazzo, old tiles and OSB for terraces and balconies











## UNIQUE GEL TECHNOLOGY

The ATLAS GEOFLEX adhesive formulation uses the innovative technology of silicate gel. The silicate gel has the unique ability to bind water. The gel fills the pores formed at the stage of adhesive setting through the network of inorganic bonds. Accumulation of a part of the mixing water ensures complete cement hydration, regardless of the type of the tiles. Thanks to appropriate water management, which is necessary to complete the setting process, the gel adhesive ensures full adhesion to substrates of various absorbency levels.

#### The use of silicate gel technology offers the following benefits:

- the possibility of bonding any type of cladding, both absorbent and non-absorbent,
- it is possible to optimally adapt the consistency of the adhesive to the individual preferences of the contractor and the needs of the application specific application, by dosing water over a much wider range than with traditional adhesives,
- achieving a full spread of adhesive under the panels, which improves the adhesion and durability of the fixing, especially in external applications,
- safe bonding of coverings on substrates exposed to direct sunlight, both during tiling work and while the adhesive mortar is setting (e.g. on balconies, terraces, etc.).

## **Properties**

ATLAS GEOFLEX is manufactured as a dry mixture of the highest quality cement binder, aggregates and specially selected modifying agents: natural and synthetic.

## The wide range of adhesive layer thicknesses (2-15 mm) allows:

- thin-bedding of cladding on an even substrate,
- thin-bedding of coverings on uneven substrates, preceded by levelling mudding,
- Thick-coat bonding of coverings on uneven substrates without the need for levelling compound.

**Zero cladding run-off** - provides the opportunity to glue the cladding 'over the top', without the need to support it at the installation stage.

It is possible to step on and grout the tile after only 12 hours - due to the accelerated setting and drying process of the mortar under the tile.

# **Purpose**

CLADDING TYPE	
glazed tiles	+
terracotta	+
porcelain tiles	+
laminated tiles	use ATLAS ULTRA GEOFLEX
natural stone cladding (granite, marble, travertine, syenite, slate, etc.).	perform an application test*
clinker	+
stoneware	+
ceramic mosaic	+
glass mosaic	perform an application test*
glass, coloured, printed tiles, etc.	perform an application test*  and check the recommendations of the tile manufacturer
concrete / cement mortar tiles	+
composite panels	use ATLAS ULTRA GEOFLEX
insulation and soundproofing panels	use ATLAS ULTRA GEOFLEX

<sup>\*</sup>for a description of the application test, see paragraph Important additional information

FORMATS OF INSTALLED ELEMENTS	
small, medium and large format tiles: $\leq 0.50 \text{ m}^2$ and with the length of the larger side $\leq 100 \text{ cm}$	+
large tile format (> 0.50 m²)	use ATLAS ULTRA GEOFLEX
slim type tiles	use ATLAS ULTRA GEOFLEX

TYPES OF OBJECT	
residential buildings	+
public, educational, office and healthcare buildings	+
commercial and service construction	+
sacral buildings	+
industrial buildings and multi-storey garages	Use ATLAS ULTRA GEOFLEX
industrial warehouses	Use ATLAS ULTRA GEOFLEX
infrastructure buildings	Use ATLAS ULTRA GEOFLEX
SPA objects	Use ATLAS ULTRA GEOFLEX

PLACE OF INSTALLATION	
low-traffic areas	+
medium traffic areas	+
high traffic areas	use ATLAS ULTRA GEOFLEX
kitchen, bathroom, laundry room, garage (in individual housing)	+
terraces	+
balconies, loggias	+
external slab stairs	+
external post stairs, e.g. cantilever stairs	use ATLAS ULTRA GEOFLEX
traffic routes	+
facades (including on thermal insulation systems)	use ATLAS ULTRA GEOFLEX
cladding of building plinths	+
process tanks, swimming pools, fountains, jacuzzis, balneotechnology (without aggressive chemicals)	use ATLAS ULTRA GEOFLEX
drinking water tanks	use ATLAS PLUS
saunas	use ATLAS ULTRA GEOFLEX
showers, washing facilities, rooms washed with large quantities of water	+

substrate type - standard	
cement floors and screeds	+
anhydrite screeds	+
cement and cement-lime plasters	+
gypsum plasters	+
cellular concrete	+
brick or silicate block walls	+
brick or hollow brick walls	+
gypsum block masonry	+

substrate type - difficult	
concrete	+
terrazzo	+
mineral, dispersion and reactive sealing coatings	+
plasterboard drywall	+
screeds (cement or anhydrite) with water or electrical underfloor heating,	+
screeds with heating mat embedded in the adhesive	+
plaster with wall heating	+
gypsum boards	+
gypsum fibre boards	+
cement fibre boards	+
existing ceramic or stone cladding (tile on tile)	only inside
resin varnishes for concrete bound to the substrate	+
dispersive, oil painting coats, bonded with substrate	+
timber floors (thickness >25mm)	use ATLAS ULTRA GEOFLEX
OSB/3, OSB/4 and particle board on the floor (thickness > 25 mm)	+
OSB/3, OSB/4 and particle board on the wall (thickness > 18mm)	+
metal and steel surfaces	use ATLAS ULTRA GEOFLEX
plastic surfaces	use ATLAS ULTRA GEOFLEX

ATLAS GEOFLEX adhesive is also used for filling the abovementioned standard and difficult substrates.

# **Technical data**

Bulk density	approx. 1.4 g/cm <sup>3</sup>
,	0.26 ÷ 0.33 l / 1 kg
Mixing ratio	1.3 ÷ 1.65 l / 5 kg
(water/dry mix)	5.85 ÷ 7.43 l / 22.5 kg
	6.5 ÷ 8.25 l / 25 kg
Min/max. adhesive thickness	2 mm ÷ 15 mm
Temperature of the adhesive preparation and of the substrate and surroundings during the work	from +5 °C to +35 °C
Maturation time	5 minutes
Service life (stand-by time)*	approx. 4 hours
Open time*	min. 30 minutes
Adjustability*	20 minutes
Walking on the floor/jointing*	after 12 hours
Full operational loads - pedestrian traffic*	after 3 days
Full operational loads - wheeled traffic*	after 14 days
Underfloor heating (heated surfaces)*	after 14 days

<sup>\*)</sup> The times shown in the table are recommended for application conditions of approx. 23  $^{\circ}$ C and 55  $^{\circ}$ humidity.

# **Technical requirements**

The product meets the requirements of PN-EN 12004+A1:2012 - type C2TE - adhesive for tiles, cementitious tile adhesive with increased parameters, extended open time and reduced run-off, for indoor and outdoor use on walls and floors.

ATLAS GEOFLEX (2019) Declaration of performance 186/1/CF EN 12004:2007+A1:2012	PR.
Intended use: Any interior and exterior installation	n of tiles
Reaction to fire	A1/A1 <sub>fl</sub>
Bond strength defined as: initial bonding	≥ 1.0 N/mm²
Bond durability in conditioning/thermal ageing conditions defined as: bonding after thermal ageing	≥ 1.0 N/mm²
Bond durability in water/damp conditions defined as: bonding after immersion in water	≥ 1.0 N/mm²
Bond durability in freeze-thaw cycles conditions defined as: bonding after freeze-thaw cycles	≥ 1.0 N/mm²

# Substrate preparation

#### The substrate should be:

**stable** - sufficiently load-bearing, resistant to deformation, free of substances that reduce adhesion and seasoned.

**even** - the maximum thickness of the adhesive is 15 mm, for levelling substrates with larger irregularities, e.g. ATLAS ZW 330 levelling mortar, ATLAS SMS, SAM or POSTAR underlays can be used.

**cleaned** - from layers that may impair adhesion of the adhesive, in particular from dust, dirt, lime, oil, grease, wax, oil and emulsion paint residues. Substrate covered with algae, mould fungi etc., should be cleaned and protected with ATLAS MYKOS NR 1 or ATLAS MYKOS PLUS,

## primed with:

- ATLAS UNI-GRUNT or ATLAS UNI-GRUNT ULTRA when the substrate has excessive or non-uniform absorptivity,
- ATLAS GRUNTO-PLAST when the substrate has low absorption or is covered with layers limiting adhesion,
- ATLAS ULTRAGRUNT when tiles will be fixed on critical substrates. **insulated -** when laying tiles on surfaces that are exposed to water.

Detailed indications for the preparation of the substrate, depending on the type of substrate, are shown in the table at the end of the Technical Data Sheet.

# **Cladding installation**

#### Preparation of the adhesive

Pour the contents of the bag into a vessel with a measured amount of water (proportions given in the Technical Data) and mix with a slow-speed mixer with a mortar mixer until a uniform consistency is obtained. Set the mixed adhesive aside for 5 minutes and mix again. The adhesive thus prepared should be used within approximately 4 hours.

#### Application of adhesive

It is recommended to first rub a thin layer of adhesive into the substrate and then apply a thicker layer of adhesive, immediately profiling it with a notched trowel. It is recommended that the toothed trowel is guided in one direction as much as possible. On walls, it is recommended to profile the adhesive in a vertical direction.

In the case of tiles laid on floors and cladding carried out out outdoors, it is recommended that the bonding surface is complete (if necessary, use a combined method of applying adhesive mortar to the substrate and to the undersurface of the tile).

#### Bonding the cladding

After spreading on the substrate, the adhesive retains its properties for approximately 30 minutes (at a temperature of approximately 23 °C and 55 % humidity). During this time, apply the tile to it and press down carefully (the contact area between the tile and the adhesive should be even and as large as possible - min. 2/3 of the tile surface). Excess adhesive appearing in the joints when pressing the tiles should be removed continuously.

Maintain joint widths according to tile size and conditions

#### Correcting the position of the plate

The position of the tile can be corrected by gently moving it in the plane of bonding. This can be done up to approximately 20 minutes after pressing (at a temperature of approx. 23 °C and 55 % humidity).

#### Grouting and use of the cladding

The use of ATLAS mortars, e.g. ATLAS CERAMIC GROUT, is recommended for grouting the cladding. It is possible to step on the cladding and start grouting approximately 12 hours after the tiles have been glued. The mortar reaches its service strength after 3 days (information given in the Technical Data). Expansion joints between tiles, joints along wall corners, joints at sanitary facilities should be filled with ATLAS ELASTIC SANITARY SILIKONE or ATLAS SANITARY SILIKONE SILTON S.

### Consumption

The average adhesive consumption figures given in the table refer to application on an even substrate. Unevenness of the substrate increases the unit consumption of the adhesive mortar.

Tile size [cm]	Place of application	Recommende d trowel tooth size [mm]	Consumptio n rate [kg/m²]
22	wall	4	1,3
2 x 2	flooring	4	1,3
10 10	wall	4	1,3
10 x 10	flooring	6	2,0
1E v 60	wall	6	2,0
15 x 60	flooring	8	2,5
20 v 2F	wall	6	2,0
20 x 25	flooring	8	2,5
25 x 40	wall	6	2,0
25 X 40	flooring	8	2,5
30 x 30	wall	6	2,0
30 X 30	flooring	8	2,5
30 v C0	wall	8	2,5
30 x 60	flooring	10	3,0
40 x 40	wall	8	2,5
40 X 40	flooring	10	3,0
50 x 50	wall	8	2,5
30 X 30	flooring	10	3,0
60 x 60	wall	10	3,0
00 X 00	flooring	12	3,5
70 x 70	wall	10	3,0
70 X 70	flooring	12	3,5
tiles of the type	wall	8	2,5
board*, e.g. 20 x 90 or 15 x 100	flooring	10	3,0

<sup>\*</sup>for plank-type tiles, a combined laying method is recommended

When using the mix combined method, the adhesive consumption will increase. When bonding floor coverings, using a 12 mm trowel with semi-circular teeth (flowing consistency 8.25 l water/25 kg mortar) - consumption 4.6 kg/m<sup>2</sup>.

# **Packaging**

Plastic bags: 25 kg, 22.5 kg

Alubag: 5 kg

# Safety information

Safety information is provided on the product packaging and in the Safety Data Sheet available at <a href="https://www.atlas.com.pl">www.atlas.com.pl</a>.

# Storage and transport

Information on storage and transport is provided on the product packaging and in the Safety Data Sheet available at <a href="https://www.atlas.com.pl">www.atlas.com.pl</a>.

The shelf life of the product is:

- for product in plastic bags 12 months from the production date shown on the packaging,
- for product in alubag 24 months from the production date shown on the packaging.

# Important additional information

Spreading under the tile is achieved using a quantity of baking water from the upper end of the mixing ratio range, i.e. approximately 0.33 l per 1 kg of dry mix. Zero run-off is achieved using a quantity of baking water from the lower end of the mixing ratio interval, i.e. approximately 0.26 l per 1 kg of dry mix.

When cladding a balcony or terrace, the subfloor should be divided by expansion joints into areas of max. 3 x 3 m.

It is possible to increase the size of the subfloor dilatation areas to  $25\ m^2$  provided that forced dilatation is carried out in the cladding itself (min. 4 cladding fields recommended, each with an area of up to  $9\ m^2$ ). When making the expansion fields, observe the requirement that the ratio of the shorter side to the longer side should be between 1:1 and 1:2. The expansion joints of the substrate should be transferred to the cladding and filled with ATLAS SILIKON SANITARNY ELASTIC or ATLAS SILIKON SANITARNY SILTON S.. Forced expansion joints should be ATLAS SILIKON SANITARY ELASTIC or ATLAS SILIKON SANITARY SILTON S. The minimum thickness of the adhesive after pressing the tiles should be 4 mm. The adhesive must fill the entire space between the tile and the substrate.

All indicated technological break times, technical parameters of the product, etc. refer to standard setting conditions, i.e. at the temperature: +23°C (+/-2°), relative humidity: 55% (+/- 5%) and substrates as defined in EN 1323 and tiles according to EN 176. In other heat and humidity conditions the indicated times may change.

Do not soak the tiles before gluing. When determining the thickness of the adhesive under the cladding to be glued, geometric deviations in the shape of the tiles, e.g. curling of the plane, must be taken into account.

Before fixing natural stone tiles or glass elements, it is necessary to carry out an application test. For this purpose, one tile should be glued to the substrate. The bonding area should be 60 % (40 % of the tile surface should not be in contact with the adhesive). After 2-3 days, the appearance of the tile should be assessed. The test result can be considered positive if there are no shade differences on the tile surface between areas in contact and not in contact with the adhesive.

The open time - from the application of the adhesive to the substrate to the application of the tiles - is limited. To check whether it is still possible to stick the tiles, a simple test is recommended. This consists of pressing the fingers of your hand against the applied adhesive. If the glue remains on the fingers, then the tiles can be glued. When the adhesive does not stick to the fingers, remove it from the substrate and apply a new layer.

Clean the tools with clean water, directly after using the adhesive. Difficult to remove remains of the bonded adhesive should be washed off with ATLAS CEMENT AWAY.

The information included in the Product Data Sheet constitutes basic guidelines concerning the use of the product and does not release from the obligation to conduct work according to the best construction practices and health and safety at work regulations. On the date of issue of this Product Data Sheet, all previous Product Data Sheets become invalid. The accompanying documents for the product are available at <a href="https://www.atlas.com.pl">www.atlas.com.pl</a>.

The content of the Product Data Sheet as well as the symbols and trade names used in it are the property of Atlas sp. z o. o. Their unauthorized use will be sanctioned.

Update date: 2022-05-13

The table below shows the specific requirements for substrate preparation. Before starting work, also refer to the Technical Sheets of the products listed in the table. The times shown in the table are recommended for application and seasoning conditions of approx. 20 °C and 50 % humidity.

Moisture content of the substrate 4.0 % CM - after approx. 1.5 days for a primer thickness of 1.0-3.0 cm - after approx. 3 days for a substrate thickness of 3.1-5.0 cm - after approx. 9 days for a substrate thickness of 5.1-10.0 cm	
- after approx. 3 days for a substrate thickness of 3.1-5.0 cm	
- arter approx. 3 days for a substrate trickless of 3.1-3.0 cm	
- after approx. 9 days for a substrate thickness of 5.1-10.0 cm	
wly manufactured Moisture content of the substrate 4.0 % CM	
nentitious subfloors ATLAS - after approx. 1 day for an undercoat thickness of 1.0-3.0 cm	
- after approx. 2 days for a substrate thickness of 3.1-5.0 cm	
- after approx. 5 days for a substrate thickness of 5.1-8.0 cm	
wly manufactured Moisture content of the substrate 4.0 % CM	
nentitious subfloors ATLAS - after approx. 6 hours for a substrate thickness of 1.0-3.0 cm	
star 60 - after approx. 12 hours for a substrate thickness of 3.1-5.0 cm	
- after approx. 40 hours for a substrate thickness of 5.1-8.0 cm	
wly manufactured Moisture content of the substrate 4.0 % CM	
nentitious subfloors ATLAS - after approx. 3 hours for a substrate thickness of 1.0-3.0 cm	
- after approx. 6 hours for a substrate thickness of 3.1-5.0 cm	
- after approx. 18 hours for a substrate thickness of 5.1-8.0 cm	
wly manufactured Moisture content of the primer 4.0 % CM	
nentitious subfloors ATLAS - after approx. 8 hours for an undercoat thickness of 1-15 mm	
S 15	
wly manufactured Moisture content of the primer 4.0 % CM	
nentitious subfloors ATLAS - after approx. 18 hours for an undercoat thickness of 3-5 mm	
- after approx. 48 hours for an undercoat thickness of 6-10 mm	
- after approx. 72 hours for a substrate thickness of 11-20 mm	
- after approx. 96 hours for an undercoat thickness of 21-30 mm	
er cement mortar Compressive strength of at least 12 MPa.	
derlays Seasoning minimum 28 days	
Optimum moisture content < 4% by weight	
Prime with one of the emulsions:	
- ATLAS UNI-GRUNT	
- ATLAS UNI-GRUNT ULTRA	
- ATLAS UNI-GRUNT PLUS	
wly manufactured anhydrite   Moisture content of the underlay 1.0 % CM	
· · · · · · · · · · · · · · · · · · ·	
Moisture content of the underlay 0.5 % CM (when heating)	
- approx. 7 days for a thickness of 0.5-3.0 cm	
Prime with one of the emulsions:	
- ATLAS UNI-GRUNT	
- ATLAS UNI-GRUNT ULTRA	
- ATLAS UNI-GRUNT PLUS	
wly manufactured anhydrite   Moisture content of the underlay 1.0 % CM	
erlay ATLAS SAM 200 - approx. 10 days for a thickness of 2.5-4.0 cm	
- approx. 21 days for a thickness of 4.1 to 6.0 cm	
Moisture content of the underlay 0.5 % CM (when heating)	
- approx. 18 days for a thickness of 2.5-4.0 cm	
- approx. 28 days for a thickness of 4.1-6.0 cm	
If a white surface deposit has appeared while the primer is drying, it should be removed mecha	inically by
sanding and then the entire surface dusted.	-
Prime with one of the emulsions:	
- ATLAS UNI-GRUNT	
- ATLAS UNI-GRUNT ULTRA	
- ATLAS UNI-GRUNT PLUS	
wly manufactured anhydrite   Moisture content of the underlay 1.0 % CM	
lerlayments ATLAS SAM - approx. 4 days for a thickness of 2.0-4.0 cm	
- approx. 7 days for a thickness of 4.1 to 6.0 cm	
Moisture content of the underlay 0.5 % (when heating) CM	
- approx. 7 days for a thickness of 2.0-4.0 cm	
- approx. 18 days for a thickness of 4.1-6.0 cm	
Prime with one of the emulsions:	
- ATLAS UNI-GRUNT	
L ATLACTINE COLINT LICTOR	
- ATLAS UNI-GRUNT ULTRA	
- ATLAS UNI-GRUNT PLUS	
- ATLAS UNI-GRUNT PLUS nent and anhydrite underlays   Preparation in accordance with the same instructions as for normal primers. In addition, the sub-	ofloor must be
- ATLAS UNI-GRUNT PLUS	ofloor must be

Bricks or hollow bricks of calcium-	A two-layer render (render + filler) trowelled to a rough finish is required. Bonding directly to unrendered
silicate, ceramic or cellular	masonry is only possible if the geometric requirements of the substrate are met. In this case, it is necessary
concrete	to complete the wall with a full joint (or to complete the jointing) and to repair any defects and unevenness
Concrete	using ready-made mortars.
	'
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
	- ATLAS UNI-GRUNT PLUS
Cement and cement-lime plasters	Seasoning minimum 3 days for every 1 cm of thickness. Optimum moisture content < 4% CM
from ATLAS ready-mixed mortars	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
	- ATLAS UNI-GRUNT PLUS
Other cement and cement-lime	Minimum CS category III
plasters	Minimum curing time of 7 days for each 1 cm of thickness
prasters	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
	- ATLAS UNI-GRUNT PLUS
Gypsum plasters	Recommended compressive strength > 4 MPa
	Prime with one of the emulsions:
	- ATLAS UNI-GRUNT
	- ATLAS UNI-GRUNT ULTRA
	- ATLAS UNI-GRUNT PLUS
	If the gypsum plaster is made in a wet room, then it should be carefully protected against moisture, e.g. by
	applying an insulating coating of ATLAS WODER E or WODER W. Gypsum plaster should be removed.
Mortar levelled substrates	Moisture content of the underlay 1.0 % CM
ATLAS ZW 330	- 5 hours at 5 mm film thickness
/Z.6.Z.V. 656	- 10 hours at a film thickness of 10 mm
	- 20 hours for a layer thickness of 20 mm
	- 48 hours for layer thicknesses over 20 mm
Comments florens	
Concrete floors	Minimum class C16/20
	Seasoning time minimum 3 months
	Optimum moisture content < 4% by weight
	Absolutely clean off any residue from concreting separators and other substances that may impair adhesion
	Repair deficiencies, chipping and other cavities with one of the mortars:
	- ATLAS TEN-10
	- ATLAS ZW 330
	- ATLAS ZW 330 - ATLAS FILER S
	- ATLAS FILER S
Newly installed waterproofing	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT
Newly installed waterproofing with ATIAS WODER DUO ATIAS	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for
with ATLAS WODER DUO, ATLAS	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.	<ul> <li>ATLAS FILER S</li> <li>Prime with ATLAS ULTRAGRUNT</li> <li>ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation</li> <li>ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours</li> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> </ul>
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	<ul> <li>ATLAS FILER S</li> <li>Prime with ATLAS ULTRAGRUNT</li> <li>ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation</li> <li>ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours</li> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.</li> </ul>
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko	<ul> <li>ATLAS FILER S</li> <li>Prime with ATLAS ULTRAGRUNT</li> <li>ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation</li> <li>ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours</li> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the</li> </ul>
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	<ul> <li>ATLAS FILER S</li> <li>Prime with ATLAS ULTRAGRUNT</li> <li>ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation</li> <li>ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours</li> <li>ATLAS WODER DUO - possibility to install the cladding after 12 hours</li> <li>ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours</li> <li>Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.</li> <li>Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.</li> <li>the layering should be designed and executed so as to prevent deformation that could damage the cladding</li> </ul>
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours - ATLAS WODER DUO - possibility to install the cladding after 12 hours - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours - ATLAS WODER DUO - possibility to install the cladding after 12 hours - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours - ATLAS WODER DUO - possibility to install the cladding after 12 hours - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours - ATLAS WODER DUO - possibility to install the cladding after 12 hours - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls the system must not buckle under operating loads for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust prime with ATLAS ULTRAGRUNT - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S.  Lastryko  Oil paint and resin varnish coatings	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S. Lastryko  Oil paint and resin varnish coatings  OSB and plank flooring	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S. Lastryko  Oil paint and resin varnish coatings  OSB and plank flooring  Existing ceramic or stone tiling	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S. Lastryko  Oil paint and resin varnish coatings  OSB and plank flooring	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.  - assess the adhesion of the existing cladding to the substrate by tapping - remove any old tiles that have become detached from the substrate.
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S. Lastryko  Oil paint and resin varnish coatings  OSB and plank flooring  Existing ceramic or stone tiling	- ATLAS FILER S  Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.  - assess the adhesion of the existing cladding to the substrate by tapping - remove any old tiles that have become detached from the substrate.  - fill cavities, e.g. with ATLAS ZW 330 mortar
with ATLAS WODER DUO, ATLAS WODER DUO EXPRES, ATLAS WODER E, ATLAS WODER W and ATLAS WODER S. Lastryko  Oil paint and resin varnish coatings  OSB and plank flooring  Existing ceramic or stone tiling	- ATLAS FILER S Prime with ATLAS ULTRAGRUNT  - ATLAS WODER E - possibility to install cladding after 2 hours for damp insulation and after 4 hours for water insulation  - ATLAS WODER W, ATLAS WODER S - possibility to install the cladding after 24 hours  - ATLAS WODER DUO - possibility to install the cladding after 12 hours  - ATLAS WODER DUO EXPRESS - cladding installation possible after 3 hours  Thoroughly degrease the surface and, in the case of pasted terrazzo, remove the top part or all of it and make a new primer. Prime with ATLAS ULTRAGRUNT.  Remove coats with low adhesion to the substrate mechanically. Stable coatings well bonded to the substrate: sand, vacuum; oil-based coatings should be primed with ATLAS ULTRAGRUNT. Remove gypsum putty based on which the substrate has been levelled.  - the layering should be designed and executed so as to prevent deformation that could damage the cladding  - OSB/3 and OSB/4 (in accordance with EN 300:2007) with a thickness of at least 25 mm can be used for floors and at least 18 mm for walls.  - the system must not buckle under operating loads.  - for proper adhesion to the tile adhesive, roughen the surface of the substrate with abrasive paper grit 40-60 and clean off any dust.  - prime with ATLAS ULTRAGRUNT  - In rooms with higher humidity, possible swelling of the OSB boards (check the values declared by their manufacturer) or deformation of the boards must be taken into account. In this case, the system constituting the substrate for the tiles should be protected against moisture. ATLAS WODER W or WODER E waterproofing can be used for this purpose.  - assess the adhesion of the existing cladding to the substrate by tapping - remove any old tiles that have become detached from the substrate.